



11/15/2017

Concord Stage Coach

PARTS LIST MS6001

PART #	ITEM	QUANTITY	DESCRIPTION/NOTES
BRITANNIA CASTINGS 6			
WP6001	Standard front right	1	
WP6002	Standard front left	1	
WP6003	Standard rear right	1	
WP6004	Standard rear left	1	
WP6005	Reach draw bolt	12	
WP6006	Strut front upper	2	
WP6007	Strut front lower	2	
WP6008	Strut rear upper	2	
WP6009	Strut rear lower	2	
WP6010	Thrust brace	4	
WP6011	Sway brace	2	
WP6012	Step bracket	2	
WP6013	Hound truss bottom	2	
WP6014	Hound truss side	2	
WP6015	Drivers seat brace	2	
WP6016	Double tree iron	2	
WP6017	Door handle	2	
WP6018	Front boot step bracket	2	
WP6019	Brake bar keeper	2	
WP6020	Front axle	1	
WP6021	Rear axle	1	
MISCELLANEOUS FITTINGS AND MATERIAL			
WP6023	Wheels hub	4	
WP1705	Photo etched	1	Brass
WP0885	1/16"X3/16X4" bar	4"	
WP0886	1/32"x3/16"x5" bar	5"	
WP160K-12	Rod - 1/32" dia. X 12"	3	
WP161K-12	Rod - 3/64" dia. X 12"	6	
WP101K-12	Tube - 3/32" dia. X 12"	1	To be use instead of 3/32 dowel
WP0993	Nails	40	
WP0940	Nails small	20	
WP0428	Eyebolts	8	
WP0409	18 ga. escutcheon pins	30	
WP0404	Hex bolt brass	2	
WP0405	Hex nut brass	2	

WP0408	Flat washer	2	
WP1113	door hinge	4	
WP1112	King bolt 1.2mm dia.	1	Brass
WP1111	Hex nut M 1.2 thread	2	Steel
WP0481	Chain	12"	
WP0567	Sail cloth 6" x 9"	1	
WPDRL22655	Drill bit #55	1	
WPDRL22666	Drill bit #66	1	
WPDRL22672	Drill bit #72	1	
WP0955	Split rings	10	
WP7540	Fiber material 1/64"x 7.5"x36"	1	
WP1704	Decal set	1	Before using decals spray with a clear coat

WOOD DOWELS

Note: All dowels are Beech unless otherwise noted. Dowels are supplied in lengths as noted. Cut to length as required.

WP5101-24	1/8" x 12"	1
-----------	------------	---

WOOD STRIPS, SHEETS, AND BLOCKS

Note: All wood is Basswood or Limewood (European Basswood) unless otherwise noted. Wood strips, sheets, and blocks are supplied in lengths as noted. Cut to length as required.

STRIPS

WP3604-24	.020" x 1/8" x 24"	3
WP3618-24	1/16" x 1/16" x 24"	3
WP3620-24	1/16" x 1/8" x 24"	2
WP3624-24	1/16" x 1/2" x 24"	4
WP3625-24	3/32" x 3/32" x 24"	2
WP3631-24	1/8" x 1/8" x 24"	1

LASER-CUT WOOD PARTS

Note: All Laser-Cut wood is Basswood or Limewood European Basswood unless otherwise noted.

WP4631-A	<u>3/16" Thick</u>	<u>1</u>
	SC1	
WP4646-B	<u>1/4" Thick</u>	<u>1</u>
	SC2	
WP4655-C	<u>1/32" Thick ply</u>	<u>1</u>
	SC3	
WP4328-D	<u>1/8" Thick</u>	<u>1</u>
	SC4	
WP4620-E	<u>3/16" Thick ply</u>	<u>1</u>
	SC5	
WP4628-F	<u>1/8" Thick</u>	<u>1</u>
	SC6	
WP4638-H	<u>1/16" Thick</u>	<u>1</u>
	SC7	
WP4634-I	<u>1/32" Thick</u>	<u>1</u>
	SC8	

WP4656-J	<u>1/64" Thick PLY</u>	<u>1</u>
	SC9	
WP4656-K	<u>1/64" Thick PLY</u>	<u>1</u>
	SC9A	
WP4633-L	<u>1/16" Thick PLY</u>	<u>1</u>
	SC10	
WP3157-M	<u>1/32" Thick Gasket material</u>	<u>1</u>
	*SC11	
WP4616-N	<u>5/32" Thick</u>	<u>1</u>
	SC12	
WP4620-0	<u>3/16" Thick PLY</u>	<u>1</u>
	SC13	

PLANS AND INSTRUCTIONS

WP6001MB	Instruction Manual	1
WPPL6001 -A	Plan set of 4 sheets	1
WPPL6001 -B	laser Identifier sheets	3
WPPL6001 -C	Casting / photoetched identifier sheets	3
WPPL6001 -D	Patterns sheets (card stock)	2
WPPL6001 -E	Wheels construction patterns	2
WPPL6001	Parts List	1

NOTE:

- PLEASE USE 3/32 ALUMINUM TUBE INSTEAD OF 3/32 DOWEL.
- Before painting hubs spray with aluminum primer.
- The laser cut square nuts in your kit are somewhat delicate. It is best to clear the center holes before removing the nuts from the sheet.
To do this use an appropriate size drill bit holding the nut down to a suitable surface. In some cases the centers will fall out, in other cases they must be coaxed out.
Cut the tabs holding the nuts in the sheet and cut the nuts apart with a sharp blade. Handle carefully when installing.